

## Accessories

### Cleaner set



This device is available for eliminating noisy volume and gathering the exhausted oil from the exhaust hole. The device contributes to clean environment.

Parts Number	Air hoist		Mass (kg)
LHP001343	EHL-025TS EHL-05TS	EHL-049TS EHL-1TW	1.0
LHP001388	EHL-1TS	EHL-2TW	1.0
LHP001389	EHL-3TS	EHL-6TW	1.6

### Overload protector



This device stops the operation automatically when it exceeds rating load.

Model	Air hoist	Mass (kg)
OP-05TS	EHL-05TS	2.0
OP-1TW	EHL-1TW	2.2
OP-1TS	EHL-1TS	6.2
OP-2TW	EHL-2TW	6.2
OP-3TS	EHL-3TS	22.0
OP-6TW	EHL-6TW	22.0

### Pendant control switch PCS-1 / PCS-2

Optional pendant controls are available to replace the standard pull rope.

Model	Air hoist		Mass (kg)
PCS-1	EHL-025TS	EHL-049TS	2.3
PCS-1BV	EHL-05TS	EHL-1TW	2.7
PCS-2	EHL-1TS	EHL-2TW	2.7
	EHL-3TS	EHL-6TW	
PCS-2BV1	EHL-1TS	EHL-2TW	3.2
PCS-2BV2	EHL-3TS	EHL-6TW	3.5

Note) Max. control tube extension is up to 6m (total lengths of hose must be less than 8m).



When you push the emergency stop button, the shut-off valve closes main air supply then stops the hoist movement compulsorily.

PCS-1/2

PCS-1BV/2BV  
(Emergency stop included)

## Options

### Stainless steel load chain

Due to the low breaking load of this type of chain, the nominal capacity of EHL-1TS, EHL-2TW would be reduced 20% (800 kg and 1,600 kg each). For 3 tons and 6 tons hoist, no stainless chain is available.

### Chain buckets

ENDO supplies a chain bucket for the undermentioned chain lengths.

Model / chain lengths	6m	10m	12m	20m
AT-60K / AT-125K	○		△	△
EHL-025TS / EHL-049TS	○		△	△
EHL-05TS / EHL-1TW	○		△	△
EHL-1TS / EHL-2TW	○		△	△
EHL-3TS / EHL-6TW	○	△		

Note) 1. ○ mark means a standard bucket.  
2. △ mark means an optional bucket.  
3. When you need the bucket capable of the other chain lengths, contact our distributor or ENDO.